

Shanklin[®] T6H, T6HCL, & T6HCR Spare Parts

Shanklin[®] customers who operate a T6H, T6HCL, or T6HCR system should carry the following spare parts on-site at all times. Readily available spare parts and timely preventative maintenance procedures can reduce downtime, improve efficiency, and increase the lifespan of your Shanklin[®] system. Spare parts can be ordered individually or as a kit.

T6H, T6HCL, & T6HCR Spare Parts Kit

Part #	Description	Quantity
T6232AF	T6HCL & T6HCR Spare Parts Kit	1

T6H, T6HCL, & T6HCR Kit Components

Part #	Description	Quantity
EA-0114	CONTACTOR, 230V	1
EB-0324	BLOCK, CONTACT, 1NO, 2 ACROSS	1
EB-0325	BLOCK, CONTACT, 1NC, 2 ACROSS	1
EE-0450	CAPACITOR, .47 MFD	1
EJ-0142	CONTROL, OVER-TEMPERATURE	1
EJ-0183	CONTROL, TEMPERATURE, GEFRAN	1
EJ-0018	CONTROL, MOTOR	1
SPA-0230-003	PROBE, THERMOCOUPLE, 96" LG	1
EK-0001	HEATER, FIN STRIP 2500W/240V 24.75 LG	1
SA-0023	SPRING, COMPRESSION, 7/16"*7/8" LG	1

Contact Shanklin[®] Customer Experience with the model and serial number of your equipment to verify that the kit you order is in compliance with your Shanklin[®] system. Different models of the same Shanklin[®] system can require slightly different parts.

Shanklin[®] Customer Experience is available to answer questions, provide quotes for spare parts, and place orders. Email shanklinparts@sealedair.com or call (866) 997-7273.